

ADJUSTMENTS

1. Video projector may need to be adjusted for convergence, keystoneing, ballooning, and other video problems. **There should be a technician available who knows the setup/adjustments of this projector.**
2. On video projector, adjust Hue control during color bars.
3. On video projector, adjust Picture or Black or Brightness control for full, rich blacks (usually has to be turned down from center position). Use 3 black chips in color bars, adjust so only the lightest chip is visible.
4. On Video Projector, adjust Color control so that colors are not too saturated or streaky.
5. Verify stereo channels using L/R test tones after color bars.
6. **Verify that loudspeakers have a matched sound.** The L/R Stereo Test (white noise bursts) on the videocassette (just before the program) should sound identical; if one speaker sounds muffled, it has a defective tweeter or crossover network.